

KVD1SHL

Key #	Description	Order ID #	Key #	Description	Order ID #
1	FRAME	DY-104360130	61	TENSION WASHER	DY-100073011
2	CLUTCH BAR PLATE-R	DY-102881010	62	SPOOL SPACER-B	DY-100074011
3	CLUTCH BAR PLATE-L	DY-102882010	63	LOCKING PIN	DY-102903070
4	CLUTCH BAR	DY-102707010	64	E-RING	DY-100621010
6	CLUTCH BAR SCREW	DY-104739010	65	LOCKING PIN SPRING	DY-101308010
7	LEVEL WIND ASSEMBLY	DY-103715010	66	GEAR SIDE COVER SCREW-A	DY-100035020
8	PIPE	DY-101406010	67	GEAR SIDE COVER SCREW-B	DY-100028020
9	WORM SHAFT	DY-100017013	69	LUBE PORT CAP	DY-101698410
10	BALL BEARING	DY-102954010	70	LUBE PORT CAP SCREW	DY-101507010
12	IDLER-S	DY-100019010	71	DRAG SPRING WASHER	DY-100088010
13	WORM SHAFT PIN	DY-100020010	72	CLICK PLATE ASSEMBLY	DY-U00188030
15	WORM SHAFT BUSHING-B	DY-102438010	73	STAR DRAG	DY-104356130
16	WORM SHAFT WASHER	DY-100539030	73X	STAR DRAG COMPLETE	DY-U04356130
17	E-RING	DY-100047010	74	CLICK LEAF SPRING	DY-102002010
18	PILLAR	DY-104359010	75	CLICK PLATE-B	DY-100188030
19	LEVEL WIND PIN	DY-100464011	77	HANDLE WASHER	DY-100933010
20	SPACER(OPTIONAL)	DY-100025020	78	HANDLE	DY-U01807032
21	LEVEL WIND NUT	DY-100288021	78X	HANDLE COMPLETE	DY-101806550
22	FRONT COVER	DY-104363080	79	BALL BEARING	DY-102950010
23	FRONT COVER SCREW	DY-103235020	80	HANDLE KNOB	DY-103069140
25	CRANK SHAFT	DY-104376010	81	BALL BEARING	DY-102950010
26	IDLER-L WASHER-A	DY-100647050	82	HANDLE KNOB SCREW	DY-100180010
27	IDLER-L	DY-101938020	83	HANDLE KNOB CAP	DY-103816060
28	IDLER-L WASHER-B	DY-100646010	85	HANDLE NUT	DY-104676020
29	BEARING PLATE	DY-104413010	86	HANDLE NUT RETAINER	DY-103642020
30	E-RING	DY-100047010	87	SCREW	DY-101202020
31	BEARING PLATE SCREW	DY-100028070	88	SPOOL	DY-U05440010
33	CLUTCH CAM	DY-102939010	88X	SPOOL COMPLETE	DY-105112010
34	CLUTCH SPRING	DY-102690010	89	BALL BEARING	DY-100156010
35	KICK LEVER	DY-102308011	90	PIN	DY-104399010
36	KICK LEVER SPRING	DY-104146010	91	BRAKE HOLDER	DY-101824010
37	CAM PLATE	DY-104364010	92	BRAKE SHOE	DY-100522010
38	CAM PLATE SCREW	DY-101177050	93	BRAKE SHOE SPRING	DY-100525010
39	PINION YOKE	DY-102083010	94	MAGNET PLATE	DY-101826110
40	PINION GEAR	DY-104372010	95	MAGNET PLATE SCREW	DY-100526010
41	PINION YOKE SPRING	DY-102465010	96	PALM SIDE PLATE	DY-104408110
42	RATCHET	DY-101407010	96X	PALM SIDE PLATE ASSEMBLY	DY-U04362100
43	RATCHET WASHER	DY-103772010	98	CONTROL DIAL	DY-102917060
44	DRIVE GEAR	DY-102965010	99	SPOOL COVER ASSEMBLY	DY-102933010
45	DRAG WASHER-L	DY-102377011	100	MAGNET HOLDER ASSEMBLY	DY-U02922010
46	DRAG WASHER-D1	DY-100057020	105	SPOOL COVER SCREW	DY-100141010
47	DRAG WASHER-A	DY-100985010	106	SPOOL SPACER-A	DY-101850010
48	DRAG WASHER-D2	DY-100986011	107	BALL BEARING	DY-102971010
50	SLEEVE	DY-104537010	108	BEARING RETAINER	DY-102976010
51	GEAR SIDE PLATE	DY-104407200	116	CAM PLATE SCREW	DY-103013020
51X	GEAR SIDE PLATE ASSEMBLY	DY-U04361200	121	SLIDE CAM SPRING	DY-102665010
53	ONE WAY CLUTCH	DY-102090010	122	SLIDE CAM-H	DY-102395010
54	O-RING	DY-103165010	123	SLIDE CAM SCREW	DY-100526020
55	BALL BEARING	DY-102381010	124	SLIDE CAM-D	DY-102394010
56	BEARING RETAINER	DY-104461010	125	CLICK SPRING	DY-102002010
57	CAST CONTROL CAP	DY-102254171	126	SPOOL COVER SPACER(OPTIONAL)	DY-102635020
57X	CAST CONTROL CAP ASSEMBLY	DY-U02254171	127	LINK PLATE	DY-102894010
58	CLICKER	DY-101674011	128	LINK PLATE SCREW	DY-103014010
59	CLICK PLATE	DY-101675011	133	HOOK HOLDER	DY-102943020
60	CLICK PLATE RETAINER	DY-101543012	134	HOOK HOLDER WASHER	DY-101168020
			135	HOOK HOLDER SCREW	DY-100246030
			136	HOOK HOLDER SPRING	DY-102969011
			155	BUSH	DY-104365010