

MCR1SHLA

Key #	Description	Order ID #		Key #	Description	Order ID #
1	FRAME	DY-104990010		62	SPOOL SPACER-B	DY-100074011
2	CLUTCH BAR PLATE-R	DY-104859010		63	LOCKING PIN	DY-103673072
3	CLUTCH BAR PLATE-L	DY-104860010		64	E-RING	DY-100621010
4	CLUTCH BAR	DY-104674010		65	LOCKING PIN SPRING	DY-101308010
6	CLUTCH BAR SCREW	DY-101507010		66	GEAR SIDE COVER SCREW-A	DY-100202020
7	LEVEL WIND ASSEMBLY	DY-103715010		67	GEAR SIDE COVER SCREW-B	DY-100202020
8	PIPE	DY-101406010		68	GEAR SIDE COVER SCREW-C	DY-100202010
9	WORM SHAFT	DY-100017013		69	LUBE PORT CAP	DY-101698440
10	BALL BEARING	DY-104544010		70	LUBE PORT CAP SCREW	DY-100202010
12	IDLER-S	DY-100019010		71	DRAG SPRING WASHER	DY-100088010
13	WORM SHAFT PIN	DY-100020010		72	CLICK HOLDER	DY-101765010
15	WORM SHAFT BUSHING-B	DY-104642010		73	STAR DRAG ASSEMBLY	DY-102946670
16	WORM SHAFT WASHER	DY-100539030		73X	STAR DRAG COMPLETE	DY-U02946670
17	E-RING	DY-100047010		74	CLICKER	DY-101763010
18	PILLAR	DY-102711010		75	CLICK PLATE	DY-101764010
19	LEVEL WIND PIN	DY-100464011		76	CLICK PLATE RETAINER	DY-101766011
20	SPACER(OPTIONAL)	DY-100025020		77	HANDLE WASHER	DY-100933010
21	LEVEL WIND NUT	DY-100288020		78	HANDLE	DY-U01807092
22	FRONT COVER	DY-104992010		78X	HANDLE COMPLETE	DY-101806590
23	FRONT COVER SCREW	DY-100152010		79	BALL BEARING	DY-104543010
24	BALL BEARING	DY-104542010		80	HANDLE KNOB	DY-103630160
25	CRANK SHAFT	DY-103144011		81	BALL BEARING	DY-104543010
27	IDLER-L	DY-101938020		82	HANDLE KNOB SCREW	DY-100180010
28	IDLER-L WASHER-B	DY-100647050		83	HANDLE KNOB CAP	DY-102309031
29	BEARING PLATE	DY-104998010		85	HANDLE NUT	DY-104096040
30	E-RING	DY-100047010		86	HANDLE NUT RETAINER	DY-103642020
31	BEARING PLATE SCREW	DY-100135010		87	SCREW	DY-101202020
33	CLUTCH CAM	DY-104993010		88	SPOOL	DY-U04736010
34	CLUTCH SPRING	DY-102690010		88X	SPOOL COMPLETE	DY-104735030
35	KICK LEVER	DY-102308011		89	BALL BEARING	DY-104540010
36	KICK LEVER SPRING	DY-104146010		90	PIN	DY-100120010
39	PINION YOKE	DY-102083010		91	BRAKE HOLDER	DY-103532010
40	PINION GEAR	DY-103620010		92	BRAKE SHOE	DY-100522010
41	PINION YOKE SPRING	DY-102465010		93	BRAKE SHOE SPRING	DY-100525010
42	RATCHET	DY-101407010		94	MAGNET PLATE	DY-103533063
43	RATCHET WASHER	DY-103772010		95	MAGNET PLATE SCREW	DY-100526010
44	DRIVE GEAR	DY-102965010		96	PALM SIDE PLATE	DY-U04997010
45	DRAG WASHER-L	DY-102377011		96X	PALM SIDE PLATE ASSEMBLY	DY-104996010
46	DRAG WASHER-D1	DY-100057020		98	CONTROL DIAL	DY-102917220
47	DRAG WASHER-A	DY-100985010		99	SPOOL COVER ASSEMBLY	DY-U04148010
48	DRAG WASHER-D2	DY-100986011		100	MAGNET HOLDER ASSEMBLY	DY-U03539010
49	SLEEVE WASHER(OPTIONAL)	DY-100086010		105	SPOOL COVER SCREW	DY-100141010
50	SLEEVE	DY-104537010		106	SPOOL SPACER-A	DY-101850010
51	GEAR SIDE PLATE	DY-104994010		107	BALL BEARING	DY-104541010
51X	GEAR SIDE PLATE ASSEMBLY	DY-U04994010		108	BEARING RETAINER	DY-102976010
53	ONE WAY CLUTCH	DY-104088010		116	CAM PLATE SCREW	DY-100293010
54	O-RING	DY-100209020		121	SLIDE CAM SPRING	DY-102665010
55	BALL BEARING	DY-104541010		122	SLIDE CAM-H	DY-103342010
56	BEARING RETAINER	DY-101588011		123	SLIDE CAM SCREW	DY-100526020
57	CAST CONTROL CAP	DY-102254161		124	SLIDE CAM-D	DY-102394010
57X	CAST CONTROL CAP ASSEMBLY	DY-U02254161		125	CLICK SPRING	DY-102002010
58	CLICKER	DY-101674011		127	LINK PLATE	DY-102894010
59	CLICK PLATE	DY-101675011		128	LINK PLATE SCREW	DY-103014010
60	CLICK PLATE RETAINER	DY-101543012		138	BUSHING-C (TLM1) (COLLAR-C)	DY-104988010
60	CLICK PLATE RETAINER	DY-101543012		141	HOOD	DY-104991010
61	TENSION WASHER	DY-100073011		142	HOOD SCREW	DY-103014010
				166	WASHER (G/METAL E-RING-BALL BEARING)	DY-100646010
				168	HOOD SCREW-B	DY-100152010