

PSP1XHL

Key #	Description	Order ID #	Key #	Description	Order ID #
1	FRAME	DY-104947040	63	LOCKING PIN	DY-103673072
2	CLUTCH BAR PLATE-R	DY-104636010	64	E-RING	DY-100621010
3	CLUTCH BAR PLATE-L	DY-104637010	65	LOCKING PIN SPRING	DY-101308010
4	CLUTCH BAR	DY-104674010	66	GEAR SIDE COVER SCREW-A	DY-100035030
5	CLUTCH LINK	DY-104651010	67	GEAR SIDE COVER SCREW-B	DY-100035020
6	CLUTCH BAR SCREW	DY-101507030	68	GEAR SIDE COVER SCREW-C	DY-100035010
7	LEVEL WIND ASSEMBLY	DY-104640020	69	LUBE PORT CAP	DY-101698440
8	PIPE	DY-103286010	70	LUBE PORT CAP SCREW	DY-100202030
9	WORM SHAFT	DY-103474010	71	DRAG SPRING WASHER	DY-100088010
10	BUSHING	DY-102605010	72	CLICK HOLDER	DY-101765010
12	IDLER-S	DY-100019010	73	STAR DRAG ASSEMBLY	DY-102946680
13	WORM SHAFT PIN	DY-100020010	73X	STAR DRAG COMPLETE	DY-U02946680
15	WORM SHAFT BUSHING-B	DY-104642010	74	CLICKER	DY-101763010
16	WORM SHAFT WASHER	DY-100539020	75	CLICK PLATE	DY-101764010
17	E-RING	DY-100047010	76	CLICK PLATE RETAINER	DY-101766011
18	PILLAR	DY-102711010	77	HANDLE WASHER	DY-100933010
19	LEVEL WIND PIN	DY-100464011	78	HANDLE	DY-U01807092
20	SPACER(OPTIONAL)	DY-100025020	78X	HANDLE COMPLETE	DY-101806580
21	LEVEL WIND NUT	DY-100288021	79	BALL BEARING	DY-104543010
22	FRONT COVER	DY-104653060	80	HANDLE KNOB	DY-103069150
23	FRONT COVER SCREW	DY-100152010	81	BALL BEARING	DY-104543010
24	BALL BEARING	DY-104542010	82	HANDLE KNOB SCREW	DY-100180010
25	CRANK SHAFT	DY-105266010	83	HANDLE KNOB CAP	DY-103816070
27	IDLER-L	DY-101938020	85	HANDLE NUT	DY-104096100
28	IDLER-L WASHER-B	DY-100647050	86	HANDLE NUT RETAINER	DY-103642160
29	BEARING PLATE	DY-104413010	87	SCREW	DY-101202020
30	E-RING	DY-100047010	88	SPOOL	DY-U05194010
31	BEARING PLATE SCREW	DY-100028070	88X	SPOOL COMPLETE	DY-105193010
34	CLUTCH SPRING	DY-102690010	89	BALL BEARING	DY-100156010
35	KICK LEVER	DY-102308011	90	PIN	DY-104399010
36	KICK LEVER SPRING	DY-104146010	91	BRAKE HOLDER	DY-103670010
37	CAM PLATE	DY-104652010	92	BRAKE SHOE ASSEMBLY	DY-103272010
38	CAM PLATE SCREW	DY-100035050	94	BRAKE HOLDER PLATE	DY-103671010
39	PINION YOKE	DY-102083010	95	BRAKE HOLDER PLATE SCREW	DY-100526010
40	PINION GEAR	DY-104373010	96	PALM SIDE PLATE	DY-U04647080
41	PINION YOKE SPRING	DY-102465010	96X	PALM SIDE PLATE ASSEMBLY	DY-104656080
42	RATCHET	DY-101407010	98	CONTROL DIAL	DY-102917300
43	RATCHET WASHER	DY-103772010	99	SPOOL COVER	DY-104747010
44	DRIVE GEAR	DY-102966020	105	SPOOL COVER SCREW	DY-103423010
45	DRAG WASHER-L	DY-102377011	106	SPOOL SPACER-A	DY-101850010
46	DRAG WASHER-D1	DY-100057020	107	BALL BEARING	DY-100155010
47	DRAG WASHER-A	DY-100985010	108	BEARING RETAINER	DY-102976010
48	DRAG WASHER-D2	DY-100986010	117	CLUTCH WASHER	DY-100539030
49	SLEEVE WASHER(OPTIONAL)	DY-100086060	118	CLUTCH SCREW	DY-103013020
50	SLEEVE	DY-104537010	120	BRAKE PLATE HOLDER ASSEMBLY	DY-103559010
51	GEAR SIDE PLATE	DY-104654120	121	SLIDE CAM SPRING	DY-102665010
51X	GEAR SIDE PLATE ASSEMBLY	DY-U04654120	122	SLIDE CAM-H	DY-103342010
53	ONE WAY CLUTCH	DY-101515010	123	SLIDE CAM SCREW	DY-100526020
54	O-RING	DY-100209020	124	SLIDE CAM-D	DY-102394010
55	BALL BEARING	DY-102381010	125	CLICK SPRING	DY-102002010
56	BEARING RETAINER	DY-104461010	126	SPOOL COVER SPACER(OPTIONAL)	DY-103567010
57	CAST CONTROL CAP	DY-102254161	133	HOOK HOLDER	DY-102943020
57X	CAST CONTROL CAP ASSEMBLY	DY-U02254161	134	HOOK HOLDER WASHER	DY-101168020
58	CLICKER	DY-101674011	135	HOOK HOLDER SCREW	DY-100246030
59	CLICK PLATE	DY-101675011	136	HOOK HOLDER SPRING	DY-102969011
60	CLICK PLATE RETAINER	DY-101543012	155	BUSH	DY-104365010
61	TENSION WASHER		166	WASHER (G/METAL E-RING-BALL BEARING)	DY-100646010
62	SPOOL SPACER-B		167	GEAR SIDE COVER SCREW-D	DY-100202020