

SS1SHG3

Key #	Description	Order ID #		Key #	Description	Order ID #
1	FRAME	DY-106150010		56	BEARING RETAINER	DY-104461010
2	CLUTCH BAR PLATE-R	DY-104859010		57	CAST CONTROL CAP	DY-105866010
3	CLUTCH BAR PLATE-L	DY-104860010		61	TENSION WASHER	DY-100834010
4	CLUTCH BAR	DY-104674010		62	SPOOL SPACER-B	DY-100690010
6	CLUTCH BAR SCREW	DY-104739010		66	GEAR SIDE COVER SCREW-A	DY-104086010
7	LEVEL WIND ASSEMBLY	DY-105527030		67	GEAR SIDE COVER SCREW-B	DY-101507010
8	PIPE	DY-101406010		69	LUBE PORT CAP	DY-103305320
9	WORM SHAFT	DY-100017013		70	LUBE PORT CAP SCREW	DY-101507030
10	BALL BEARING	DY-102954010		71	DRAG SPRING WASHER	DY-100088010
12	IDLER-S	DY-100019010		72	CLICK PLATE ASSEMBLY	DY-U00188010
13	WORM SHAFT PIN	DY-100020010		73	STAR DRAG	DY-105837070
15	WORM SHAFT BUSHING-B	DY-104642010		77	HANDLE WASHER	DY-100933010
16	WORM SHAFT WASHER	DY-100539030		78	HANDLE	DY-U06192010
17	E-RING	DY-100047010		78X	HANDLE COMPLETE	DY-106191010
18	PILLAR	DY-102711010		79	BALL BEARING	DY-102950010
19	LEVEL WIND PIN	DY-100464011		80	HANDLE KNOB	DY-105020010
20	SPACER(OPTIONAL)	DY-100025020		81	BALL BEARING	DY-102950010
21	LEVEL WIND NUT	DY-100288021		82	HANDLE KNOB SCREW	DY-100180010
22	FRONT COVER	DY-106151010		83	HANDLE KNOB CAP	DY-105023010
23	FRONT COVER SCREW	DY-100152010		85	HANDLE NUT	DY-104094150
24	BALL BEARING	DY-102952010		86	HANDLE NUT RETAINER	DY-103642020
25	CRANK SHAFT	DY-105257010		87	SCREW	DY-101202020
27	IDLER-L	DY-101938020		88	SPOOL	DY-U06223010
28	IDLER-L WASHER-B	DY-100646020		88X	SPOOL COMPLETE	DY-106222010
29	BEARING PLATE	DY-104409010		89	BALL BEARING	DY-102366010
30	E-RING	DY-100047010		90	PIN	DY-104399010
31	BEARING PLATE SCREW	DY-100028070		96	PALM SIDE PLATE	DY-106159010
33	CLUTCH CAM	DY-102893010		96X	PALM SIDE PLATE ASSEMBLY	DY-U06159010
34	CLUTCH SPRING	DY-102688010		98	CONTROL DIAL	DY-106166010
35	KICK LEVER	DY-106155010		99	SPOOL COVER	DY-106160010
36	KICK LEVER SPRING	DY-104137010		100	MAGNET HOLDER ASSEMBLY	DY-U06164010
37	CAM PLATE	DY-104354010		103	SPRING	DY-102665010
38	CAM PLATE SCREW	DY-101177050		105	SPOOL COVER SCREW	DY-103423010
39	PINION YOKE	DY-102073010		106	SPOOL SPACER-A	DY-101850010
40	PINION GEAR	DY-105847010		107	BALL BEARING	DY-102971010
41	PINION YOKE SPRING	DY-102465010		108	BEARING RETAINER	DY-102976010
42	RATCHET	DY-106087010		118	CLUTCH SCREW	DY-103013020
43	RATCHET WASHER	DY-106177010		121	SLIDE CAM SPRING	DY-102665010
44	DRIVE GEAR	DY-102868010		122	SLIDE CAM-H	DY-105585010
45	DRAG WASHER-L	DY-101531030		123	SLIDE CAM SCREW	DY-100526030
46	DRAG WASHER-D1	DY-101367010		125	CLICK SPRING	DY-105429010
49	SLEEVE WASHER(OPTIONAL)	DY-100144020		127	LINK PLATE	DY-102894010
50	SLEEVE	DY-104537010		128	LINK PLATE SCREW	DY-103014010
51	GEAR SIDE PLATE	DY-106157030		144	LOCK LEVER	DY-106161020
51X	GEAR SIDE PLATE ASSEMBLY	DY-U06157030		145	CLICK PIN SPRING	DY-103643010
52	GEAR SIDE COVER TRIM	DY-105533060		146	CLICK PIN	DY-102494010
53	ONE WAY CLUTCH	DY-104088010		147	GUIDE PIN	DY-103288020
54	O-RING	DY-100071020		155	BUSH	DY-104365010
55	BALL BEARING	DY-102381010		166	WASHER (G/METAL E-RING-BALL BEARING)	DY-100647050
				167	CONTROL DIAL SCREW	DY-104901010
				168	CONTROL DIAL WASHER	DY-100647010
				179	GEAR SIDE COVER SCREW-D	DY-100526020