

CU1SHG3

Key #	Description	Order ID #		Key #	Description	Order ID #
1	FRAME	DY-105920030		69	LUBE PORT CAP	DY-103305330
2	CLUTCH BAR PLATE-R	DY-104636010		70	LUBE PORT CAP SCREW	DY-101507040
3	CLUTCH BAR PLATE-L	DY-104637010		71	DRAG SPRING WASHER	DY-100088010
4	CLUTCH BAR	DY-105531020		72	CLICK HOLDER	DY-101765010
6	CLUTCH BAR SCREW	DY-104739020		73X	STAR DRAG COMPLETE	DY-U02715260
7	LEVEL WIND ASSEMBLY	DY-105921010		74	CLICKER	DY-101763010
8	PIPE	DY-103286010		75	CLICK PLATE	DY-101764010
9	WORM SHAFT	DY-106197010		76	CLICK PLATE RETAINER	DY-101766011
10	BALL BEARING	DY-104544010		77	HANDLE WASHER	DY-100933010
12	IDLER-S	DY-100019010		78	HANDLE	DY-U06118020
13	WORM SHAFT PIN	DY-100020010		78X	HANDLE COMPLETE	DY-106116020
15	WORM SHAFT BUSHING-B	DY-104642010		79	BALL BEARING	DY-104543010
16	WORM SHAFT WASHER	DY-100539020		80	HANDLE KNOB	DY-105020010
17	E-RING	DY-100047010		81	BALL BEARING	DY-104543010
18	PILLAR	DY-102711010		82	HANDLE KNOB SCREW	DY-100180010
19	LEVEL WIND PIN	DY-100464011		83	HANDLE KNOB CAP	DY-105023010
20	SPACER(OPTIONAL)	DY-100025020		85	HANDLE NUT	DY-104094100
21	LEVEL WIND NUT	DY-100288021		86	HANDLE NUT RETAINER	DY-103642020
22	FRONT COVER	DY-105923040		87	SCREW	DY-101202030
23	FRONT COVER SCREW	DY-100152010		88	SPOOL	DY-U06231010
24	BALL BEARING	DY-104542010		88X	SPOOL COMPLETE	DY-106230010
25	CRANK SHAFT	DY-105257010		89	BALL BEARING	DY-102970010
27	IDLER-L	DY-101938020		90	PIN	DY-104399010
28	IDLER-L WASHER-B	DY-100646010		96	PALM SIDE COVER	DY-106048020
29	BEARING PLATE	DY-104411010		96X	PALM SIDE PLATE ASSEMBLY	DY-U06048020
30	E-RING	DY-100047010		98	CONTROL DIAL	DY-106049030
31	BEARING PLATE SCREW	DY-100028070		99	SPOOL COVER	DY-105941010
33	CLUTCH CAM	DY-105750010		100	MAGNET HOLDER ASSEMBLY	DY-U05943010
34	CLUTCH SPRING	DY-102688010		105	SPOOL COVER SCREW	DY-103423010
35	KICK LEVER	DY-102307011		106	SPOOL SPACER-A	DY-101850010
36	KICK LEVER SPRING	DY-104137010		107	BALL BEARING	DY-102971010
37	CAM PLATE	DY-104639011		108	BEARING RETAINER	DY-102976010
38	CAM PLATE SCREW	DY-100035050		117	CLUTCH WASHER	DY-100539030
39	PINION YOKE	DY-102073010		118	CLUTCH SCREW	DY-103013020
40	PINION GEAR	DY-105847010		124	SLIDE CAM-D	DY-105940020
41	PINION YOKE SPRING	DY-102465010		125	CLICK SPRING	DY-105958010
42	RATCHET	DY-100818010		133	HOOK HOLDER	DY-102898020
43	RATCHET WASHER	DY-103772010		134	HOOK HOLDER WASHER	DY-101168020
44	DRIVE GEAR	DY-102871030		135	HOOK HOLDER SCREW	DY-100246030
45	DRAG WASHER-L	DY-102377011		136	HOOK HOLDER SPRING	DY-102968011
46	DRAG WASHER-D1	DY-100057020		141	HOOD	DY-106045020
47	DRAG WASHER-A	DY-100985010		142	HOOD SCREW	DY-103828030
48	DRAG WASHER-D2	DY-100986010		143	FRONT COVER SCREW-B	DY-103828030
49	SLEEVE WASHER(OPTIONAL)	DY-100086010		144	LOCK LEVER	DY-105942010
50	SLEEVE	DY-104537010		145	CLICK PIN SPRING	DY-103643010
51	GEAR SIDE PLATE	DY-106046030		146	CLICK PIN	DY-102494010
51X	GEAR SIDE PLATE ASSEMBLY	DY-U06046030		147	GUIDE PIN	DY-103288020
53	ONE WAY CLUTCH	DY-104088010		155	BUSH	DY-104365010
54	O-RING	DY-100209020		166	WASHER (G/METAL E-RING-BALL BEARING)	DY-100647050
55	BALL BEARING	DY-102381010		167	CONTROL DIAL SCREW	DY-104900010
56	BEARING RETAINER	DY-104461010		168	CONTROL DIAL WASHER	DY-105985040
57	CAST CONTROL CAP	DY-UA5882020		170	FRAME PLATE	DY-105529010
57X	CAST CONTROL CAP ASSEMBLY	DY-U05882020		171	CLUTCH BAR TRIM	DY-105532060
58	CLICKER	DY-101674011		172	CLUTCH BAR TRIM SCREW (*2)	DY-100526010
59	CLICK PLATE	DY-101675011		177	MAGNET HOLDER COVER	DY-105944020
60	CLICK PLATE RETAINER	DY-101543012		178	MAGNET HOLDER COVER SCREW (*2)	DY-104900010
61	TENSION WASHER	DY-100073011		181	FRAME DECO_A	DY-105925010
62	SPOOL SPACER-B	DY-100074021		182	FRAME DECO_B	DY-105926010
66	GEAR SIDE COVER SCREW-A	DY-100202060		190	DIAL DECO	DY-105946042
67	GEAR SIDE COVER SCREW-B	DY-100202050				