

CU1SHLG3

Key #	Description	Order ID #	Key #	Description	Order ID #
1	FRAME	DY-105950030	69	LUBE PORT CAP	DY-103305330
2	CLUTCH BAR PLATE-R	DY-104636010	70	LUBE PORT CAP SCREW	DY-101507040
3	CLUTCH BAR PLATE-L	DY-104637010	71	DRAG SPRING WASHER	DY-100088010
4	CLUTCH BAR	DY-105531020	72	CLICK HOLDER	DY-101765010
6	CLUTCH BAR SCREW	DY-104739020	73X	STAR DRAG COMPLETE	DY-U02725110
7	LEVEL WIND ASSEMBLY	DY-105921010	74	CLICKER	DY-101763010
8	PIPE	DY-103286010	75	CLICK PLATE	DY-101764010
9	WORM SHAFT	DY-106197010	76	CLICK PLATE RETAINER	DY-101766011
10	BALL BEARING	DY-104544010	77	HANDLE WASHER	DY-100933010
12	IDLER-S	DY-100019010	78	HANDLE	DY-U06118020
13	WORM SHAFT PIN	DY-100020010	78X	HANDLE COMPLETE	DY-106116020
15	WORM SHAFT BUSHING-B	DY-104642010	79	BALL BEARING	DY-104543010
16	WORM SHAFT WASHER	DY-100539020	80	HANDLE KNOB	DY-105020010
17	E-RING	DY-100047010	81	BALL BEARING	DY-104543010
18	PILLAR	DY-102711010	82	HANDLE KNOB SCREW	DY-100180010
19	LEVEL WIND PIN	DY-100464011	83	HANDLE KNOB CAP	DY-105023010
20	SPACER(OPTIONAL)	DY-100025020	85	HANDLE NUT	DY-104096100
21	LEVEL WIND NUT	DY-100288021	86	HANDLE NUT RETAINER	DY-103642020
22	FRONT COVER	DY-105951040	87	SCREW	DY-101202030
23	FRONT COVER SCREW	DY-100152010	88	SPOOL	DY-U06231010
24	BALL BEARING	DY-104542010	88X	SPOOL COMPLETE	DY-106230010
25	CRANK SHAFT	DY-105261010	89	BALL BEARING	DY-102970010
27	IDLER-L	DY-101938020	90	PIN	DY-104399010
28	IDLER-L WASHER-B	DY-100646010	96	PALM SIDE COVER	DY-106052020
29	BEARING PLATE	DY-104413010	96X	PALM SIDE PLATE ASSEMBLY	DY-U06052020
30	E-RING	DY-100047010	98	CONTROL DIAL	DY-106049040
31	BEARING PLATE SCREW	DY-100028070	99	SPOOL COVER	DY-105941010
33	CLUTCH CAM	DY-105775010	100	MAGNET HOLDER ASSEMBLY	DY-U05943010
34	CLUTCH SPRING	DY-102690010	105	SPOOL COVER SCREW	DY-103423010
35	KICK LEVER	DY-102308011	106	SPOOL SPACER-A	DY-101850010
36	KICK LEVER SPRING	DY-104146010	107	BALL BEARING	DY-102971010
37	CAM PLATE	DY-104652011	108	BEARING RETAINER	DY-102976010
38	CAM PLATE SCREW	DY-100035050	117	CLUTCH WASHER	DY-100539030
39	PINION YOKE	DY-102083010	118	CLUTCH SCREW	DY-103013020
40	PINION GEAR	DY-105852010	124	SLIDE CAM-D	DY-105940020
41	PINION YOKE SPRING	DY-102465010	125	CLICK SPRING	DY-105958010
42	RATCHET	DY-101407010	133	HOOK HOLDER	DY-102943020
43	RATCHET WASHER	DY-103772010	134	HOOK HOLDER WASHER	DY-101168020
44	DRIVE GEAR	DY-102965030	135	HOOK HOLDER SCREW	DY-100246030
45	DRAG WASHER-L	DY-102377011	136	HOOK HOLDER SPRING	DY-102969011
46	DRAG WASHER-D1	DY-100057020	141	HOOD	DY-106045020
47	DRAG WASHER-A	DY-100985010	142	HOOD SCREW	DY-103828030
48	DRAG WASHER-D2	DY-100986010	143	FRONT COVER SCREW-B	DY-103828030
49	SLEEVE WASHER(OPTIONAL)	DY-100086010	144	LOCK LEVER	DY-105957010
50	SLEEVE	DY-104537010	145	CLICK PIN SPRING	DY-103643010
51	GEAR SIDE PLATE	DY-106050030	146	CLICK PIN	DY-102494010
51X	GEAR SIDE PLATE ASSEMBLY	DY-U06050030	147	GUIDE PIN	DY-103288020
53	ONE WAY CLUTCH	DY-104088010	155	BUSH	DY-104365010
54	O-RING	DY-100209020	166	WASHER (G/METAL E-RING-BALL BEARING)	DY-100647050
55	BALL BEARING	DY-102381010	167	CONTROL DIAL SCREW	DY-104900010
56	BEARING RETAINER	DY-104461010	168	CONTROL DIAL WASHER	DY-105985040
57	CAST CONTROL CAP	DY-UA5882020	170	FRAME PLATE	DY-105557010
57X	CAST CONTROL CAP ASSEMBLY	DY-U05882020	171	CLUTCH BAR TRIM	DY-105532060
58	CLICKER	DY-101674011	172	CLUTCH BAR TRIM SCREW (*2)	DY-100526010
59	CLICK PLATE	DY-101675011	177	MAGNET HOLDER COVER	DY-105944020
60	CLICK PLATE RETAINER	DY-101543012	178	MAGNET HOLDER COVER SCREW (*2)	DY-104900010
61	TENSION WASHER	DY-100073011	181	FRAME DECO_A	DY-105925010
62	SPOOL SPACER-B	DY-100074021	182	FRAME DECO_B	DY-105926010
66	GEAR SIDE COVER SCREW-A	DY-100202060	190	DIAL DECO	DY-105946042
67	GEAR SIDE COVER SCREW-B	DY-100202050			