

# TP2SH / TP2SHL

NO	PARTNAME	NO	PARTNAME	NO	PARTNAME
1	FRAME	42	RATCHET	87	SCREW
2	CLUTCH BAR PLATE-R	43	RATCHET WASHER	88	SPOOL
3	CLUTCH BAR PLATE-L	44	DRIVE GEAR	88X	SPOOL COMPLETE
4	CLUTCH BAR ASSEMBLY	45	DRAG WASHER (L)	89	BALL BEARING
6	CLUTCH BAR SCREW	48	DRAG WASHER (D)	90	PIN
7	LEVEL WIND ASSEMBLY	49	SLEEVE WASHER(OPTIONAL)	91	BRAKE HOLDER
8	PIPE	50	SLEEVE	92	BRAKE SHOE (*4)
9	WORM SHAFT	51	GEAR SIDE PLATE	93	BRAKE SHOE SPRING (*4)
10	BALL BEARING	51X	GEAR SIDE PLATE ASSEMBLY	94	MAGNET PLATE
12	IDLER (S)	53	ONE WAY CLUTCH	95	MAGNET PLATE SCREW (*2)
13	WORM SHAFT PIN	54	O-RING	96	PALM SIDE PLATE
15	WORM SHAFT BUSHING (B)	55	BALL BEARING	96X	PALM SIDE PLATE ASSEMBLY
16	WORM SHAFT WASHER(OPTIONAL)	56	BEARING RETAINER	98	CONTROL DIAL
17	E-RING	57	CAST CONTROL CAP	99	SPOOL COVER
18	PILLAR	57X	CAST CONTROL CAP ASSEMBLY	100	MAGNET HOLDER ASSEMBLY
19	LEVEL WIND PIN	58	CLICKER	105	SPOOL COVER SCREW (*3)
20	SPACER(OPTIONAL)	59	CLICK PLATE	106	SPOOL SPACER (A)
21	LEVEL WIND NUT	60	CLICK PLATE RETAINER	107	BALL BEARING
22	FRONT COVER	61	TENSION WASHER	108	BEARING RETAINER
23	FRONT COVER SCREW	62	SPOOL SPACER (B)	114	WASHER(OPTIONAL)
24	BALL BEARING	63	LOCKING PIN	121	SLIDE CAM SPRING (*3)
25	CRANK SHAFT	65	LOCKING PIN SPRING	122	SLIDE CAM-H
26	IDLER (L) WASHER (A)	66	GEAR SIDE COVER SCREW (A*5)	123	SLIDE CAM SCREW (*3)
27	IDLER (L)	71	DRAG SPRING WASHER (*2)	124	SLIDE CAM-D
28	IDLER (L) WASHER (B)	72	CLICK PLATE ASSEMBLY	125	CLICK SPRING
29	BEARING PLATE	73	STAR DRAG	127	LINK PLATE
30	E-RING	77	LEAF SPRING	128	LINK PLATE SCREW
31	BEARING PLATE SCREW (*2)	78	HANDLE	138	BUSHING-C
33	CLUTCH CAM	78X	HANDLE COMPLETE		
34	CLUTCH SPRING	79	BUSHING (*2)		
35	KICK LEVER	80	HANDLE KNOB (*2)		
36	KICK LEVER SPRING	81	BALL BEARING (*2)		
38	CLUTCH CAM SCREW	82	HANDLE KNOB SCREW (*2)		
39	PINION YOKE	83	HANDLE KNOB CAP (*2)		
40	PINION GEAR	85	HANDLE NUT		
41	PINION YOKE SPRING (*2)	86	HANDLE NUT RETAINER		

