


# MJ1SH



Key#	Part Name	Key#	Part Name	Key#	Part Name
1	FRAME	44	DRIVE GEAR	83	HANDLE KNOB CAP
2	CLUTCH BAR PLATE-R	45	DRAG WASHER-L	85	HANDLE NUT
3	CLUTCH BAR PLATE-L	46	DRAG WASHER-D1	86	HANDLE NUT RETAINER
4	CLUTCH BAR	47	DRAG WASHER-A	87	SCREW
6	CLUTCH BAR SCREW	48	DRAG WASHER-D2	88	SPOOL
7	LEVEL WIND ASSEMBLY	49	SLEEVE WASHER(OPTIONAL)	88X	SPOOL COMPLETE
8	PIPE	50	SLEEVE	89	BALL BEARING
9	WORM SHAFT	51	GEAR SIDE PLATE	90	PIN
10	BALL BEARING	51X	GEAR SIDE PLATE ASSEMBLY	91	BRAKE HOLDER
12	IDLER-S	53	ONE WAY CLUTCH	92	BRAKE SHOE
13	WORM SHAFT PIN	54	O-RING	93	BRAKE SHOE SPRING
15	WORM SHAFT BUSHING-B	55	BALL BEARING	94	MAGNET PLATE
16	WORM SHAFT WASHER	56	BEARING RETAINER	95	SCREW
17	WORM SHAFT WASHER	57	CAST CONTROL CAP	96	PALM SIDE PLATE
18	PILLAR	57X	CAST CONTROL CAP ASSEMBLY	96X	PALM SIDE PLATE ASSEMBLY
19	LEVEL WIND PIN	58	CLICKER	98	CONTROL DIAL
20	SPACER(OPTIONAL)	59	CLICK PLATE	99	SPOOL COVER
21	LEVEL WIND NUT	60	CLICK PLATE RETAINER	100	MAGNET HOLDER ASSEMBLY
22	FRONT COVER	61	TENSION WASHER	105	SPOOL COVER SCREW
23	FRONT COVER SCREW-A	62	SPOOL SPACER-B	106	SPOOL SPACER-A
24	BALL BEARING	63	LOCKING PIN	107	BALL BEARING
25	CRANK SHAFT	64	E-RING	108	BEARING RETAINER
26	CRANK SHAFT WASHER(OPTIONAL)	65	LOCKING PIN SPRING	114	WASHER(OPTIONAL)
27	IDLER-L	66	GEAR SIDE COVER SCREW-A	116	CLUTCH CAM SCREW
28	IDLER-L WASHER-B	67	GEAR SIDE COVER SCREW-B	121	SLIDE CAM SPRING
29	BEARING PLATE	69	LUBE PORT CAP	122	SLIDE CAM-H
30	E-RING	70	LUBE PORT CAP SCREW	123	SLIDE CAM SCREW
31	BEARING PLATE SCREW	71	DRAG SPRING WASHER	124	SLIDE CAM-D
33	CLUTCH CAM	72	CLICK PLATE ASSEMBLY	125	CLICK SPRING
34	CLUTCH SPRING	73	STAR DRAG	127	LINK PLATE
35	KICK LEVER	77	HANDLE WASHER	128	LINK PLATE SCREW
36	KICK LEVER SPRING	78	HANDLE	141	HOOD
39	PINION YOKE	78X	HANDLE COMPLETE	142	HOOD SCREW-A
40	PINION GEAR	79	BALL BEARING	143	FRONT COVER SCREW-B
41	PINION YOKE SPRING	80	HANDLE YOKE SPRING	156	HOOD SCREW-B
42	RATCHET	81	BALL BEARING		
43	RATCHET WASHER	82	HANDLE KNOB SCREW		

# MJ1SHL

