

TP2SHL

Key #	Description	Order ID #		Key #	Description	Order ID #
1	FRAME	DY-105975020		61	TENSION WASHER	DY-100073011
2	CLUTCH BAR ASSEMBLY	DY-102883090		62	SPOOL SPACER-B	DY-100074011
6	CLUTCH BAR SCREW	DY-104739010		63	LOCKING PIN	DY-105916010
7	LEVEL WIND ASSEMBLY	DY-103715010		65	LOCKING PIN SPRING	DY-102665010
8	PIPE	DY-101406010		66	GEAR SIDE COVER SCREW-A	DY-100202020
9	WORM SHAFT	DY-100017013		67	GEAR SIDE COVER SCREW-B	DY-100202020
10	BALL BEARING	DY-104544010		71	DRAG SPRING WASHER	DY-100088010
12	IDLER-S	DY-100019010		72	CLICK PLATE ASSEMBLY	DY-U00188010
13	WORM SHAFT PIN	DY-100020010		73	STAR DRAG	DY-104356870
15	WORM SHAFT BUSHING-B	DY-104642010		77	HANDLE WASHER	DY-100933010
16	WORM SHAFT WASHER	DY-100539020		78	HANDLE	DY-U01807132
17	E-RING	DY-100047010		78X	HANDLE COMPLETE	DY-101806760
18	PILLAR	DY-102711010		79	BEARING	DY-100196010
19	LEVEL WIND PIN	DY-100464011		80	HANDLE KNOB	DY-103069140
20	SPACER(OPTIONAL)	DY-100025020		81	BALL BEARING	DY-104543010
21	LEVEL WIND NUT	DY-100288021		82	HANDLE KNOB SCREW	DY-100180010
22	FRONT COVER	DY-105976040		83	HANDLE KNOB CAP	DY-103816060
23	FRONT COVER SCREW	DY-100141020		85	HANDLE NUT	DY-104096150
24	BALL BEARING	DY-104542010		86	HANDLE NUT RETAINER	DY-103642220
25	CRANK SHAFT	DY-103144011		87	SCREW	DY-101202020
27	IDLER-L	DY-101938020		88	SPOOL	DY-U04736070
28	IDLER-L WASHER-B	DY-100646010		88X	SPOOL COMPLETE	DY-104735080
29	BEARING PLATE	DY-104998010		89	BALL BEARING	DY-104540010
30	E-RING	DY-100047010		90	PIN	DY-100120010
31	BEARING PLATE SCREW	DY-100135010		91	BRAKE HOLDER	DY-105271010
33	CLUTCH CAM	DY-104993010		92	BRAKE SHOE	DY-104275030
34	CLUTCH SPRING	DY-102690010		93	BRAKE SHOE SPRING	DY-100525010
35	KICK LEVER	DY-102308011		94	MAGNET PLATE	DY-105272060
36	KICK LEVER SPRING	DY-104146010		95	MAGNET PLATE SCREW	DY-100526010
39	PINION YOKE	DY-102083010		96	PALM SIDE PLATE	DY-105978040
40	PINION GEAR	DY-103620010		96X	PALM SIDE PLATE ASSEMBLY	DY-105979040
41	PINION YOKE SPRING	DY-102465010		98	CONTROL DIAL	DY-102917220
42	RATCHET	DY-101407010		99	SPOOL COVER ASSEMBLY	DY-U04148010
43	RATCHET WASHER	DY-103772010		100	MAGNET HOLDER ASSEMBLY	DY-U03539010
44	DRIVE GEAR	DY-102962010		105	SPOOL COVER SCREW	DY-100141010
45	DRAG WASHER-L	DY-101531030		106	SPOOL SPACER-A	DY-101850010
46	DRAG WASHER-D1	DY-101367010		107	BALL BEARING	DY-104541010
49	SLEEVE WASHER(OPTIONAL)	DY-100144020		108	BEARING RETAINER	DY-102976010
50	SLEEVE	DY-104537010		118	CLUTCH SCREW	DY-100293010
51	GEAR SIDE PLATE	DY-105888050		121	SLIDE CAM SPRING	DY-102665010
51X	GEAR SIDE PLATE ASSEMBLY	DY-U05888050		122	SLIDE CAM-H	DY-103342010
53	ONE WAY CLUTCH	DY-104088010		123	SLIDE CAM SCREW	DY-100526020
54	O-RING	DY-100209020		124	SLIDE CAM-D	DY-102394010
55	BALL BEARING	DY-104541010		125	CLICK SPRING	DY-102002010
56	BEARING RETAINER	DY-101588011		127	LINK PLATE	DY-102894010
57	CAST CONTROL CAP	DY-102254221		128	LINK PLATE SCREW	DY-103014010
57X	CAST CONTROL CAP ASSEMBLY	DY-U02254221		155	BUSH	DY-104988010
58	CLICKER	DY-101674011		166	WASHER (G/METAL E-RING-BALL BEARING)	DY-100647050
59	CLICK PLATE	DY-101675011				
60	CLICK PLATE RETAINER	DY-101543012				