

MJ1SHL

Key #	Description	Order ID #	Key #	Description	Order ID #
1	FRAME	DY-105865010	61	TENSION WASHER	DY-100073011
2	CLUTCH BAR PLATE-R	DY-104859010	62	SPOOL SPACER-B	DY-100074011
3	CLUTCH BAR PLATE-L	DY-104860010	63	LOCKING PIN	DY-103673072
4	CLUTCH BAR	DY-104674010	64	E-RING	DY-100621010
6	CLUTCH BAR SCREW	DY-101507010	65	LOCKING PIN SPRING	DY-101308010
7	LEVEL WIND ASSEMBLY	DY-103715010	66	GEAR SIDE COVER SCREW-A	DY-100202040
8	PIPE	DY-101406010	67	GEAR SIDE COVER SCREW-B	DY-100202060
9	WORM SHAFT	DY-100017013	69	LUBE PORT CAP	DY-101698300
10	BALL BEARING	DY-104544010	70	LUBE PORT CAP SCREW	DY-100202060
12	IDLER-S	DY-100019010	71	DRAG SPRING WASHER	DY-100088010
13	WORM SHAFT PIN	DY-100020010	72	CLICK PLATE ASSEMBLY	DY-U00188030
15	WORM SHAFT BUSHING-B	DY-104642010	73	STAR DRAG	DY-104356130
16	WORM SHAFT WASHER	DY-100539020	77	HANDLE WASHER	DY-100933010
17	E-RING	DY-100047010	78	HANDLE	DY-U01807092
18	PILLAR	DY-102711010	78X	HANDLE COMPLETE	DY-101806690
19	LEVEL WIND PIN	DY-100464011	79	BALL BEARING	DY-104543010
20	SPACER(OPTIONAL)	DY-100025020	80	HANDLE KNOB	DY-103630200
21	LEVEL WIND NUT	DY-100288021	81	BALL BEARING	DY-104543010
22	FRONT COVER	DY-104992070	82	HANDLE KNOB SCREW	DY-100180010
23	FRONT COVER SCREW	DY-100141020	83	HANDLE KNOB CAP	DY-102309031
24	BALL BEARING	DY-104542010	85	HANDLE NUT	DY-104096040
25	CRANK SHAFT	DY-105261010	86	HANDLE NUT RETAINER	DY-103642160
26	IDLER-L WASHER-A	DY-100647050	87	SCREW	DY-101202030
27	IDLER-L	DY-101938020	88	SPOOL	DY-U04736010
28	IDLER-L WASHER-B	DY-100646020	88X	SPOOL COMPLETE	DY-104735030
29	BEARING PLATE	DY-104998010	89	BALL BEARING	DY-104540010
30	E-RING	DY-100047010	90	PIN	DY-100120010
31	BEARING PLATE SCREW	DY-100135010	91	BRAKE HOLDER	DY-105271010
33	CLUTCH CAM	DY-104993010	92	BRAKE SHOE	DY-104275030
34	CLUTCH SPRING	DY-102690010	93	BRAKE SHOE SPRING	DY-100525010
35	KICK LEVER	DY-102308011	94	MAGNET PLATE	DY-105272060
36	KICK LEVER SPRING	DY-104146010	95	MAGNET PLATE SCREW	DY-100526010
39	PINION YOKE	DY-102083010	96	PALM SIDE PLATE	DY-U04997070
40	PINION GEAR	DY-103620010	96X	PALM SIDE PLATE ASSEMBLY	DY-104996090
41	PINION YOKE SPRING	DY-102465010	98	CONTROL DIAL	DY-102917400
42	RATCHET	DY-101407010	99	SPOOL COVER ASSEMBLY	DY-U04148010
43	RATCHET WASHER	DY-103772010	100	MAGNET HOLDER ASSEMBLY	DY-U03539010
44	DRIVE GEAR	DY-102965010	105	SPOOL COVER SCREW	DY-100141010
45	DRAG WASHER-L	DY-102377011	106	SPOOL SPACER-A	DY-101850010
46	DRAG WASHER-D1	DY-100057020	107	BALL BEARING	DY-104541010
47	DRAG WASHER-A	DY-100985010	108	BEARING RETAINER	DY-102976010
48	DRAG WASHER-D2	DY-100986011	116	CAM PLATE SCREW	DY-100293010
49	SLEEVE WASHER(OPTIONAL)	DY-100086030	121	SLIDE CAM SPRING	DY-102665010
50	SLEEVE	DY-104537010	122	SLIDE CAM-H	DY-103342010
51	GEAR SIDE PLATE	DY-104995070	123	SLIDE CAM SCREW	DY-100526020
51X	GEAR SIDE PLATE ASSEMBLY	DY-104994070	124	SLIDE CAM-D	DY-102394010
53	ONE WAY CLUTCH	DY-104088010	125	CLICK SPRING	DY-102002010
54	O-RING	DY-100209020	127	LINK PLATE	DY-102894010
55	BALL BEARING	DY-104541010	128	LINK PLATE SCREW	DY-103014010
56	BEARING RETAINER	DY-101588011	141	HOOD	DY-105861010
57	CAST CONTROL CAP	DY-103164220	142	HOOD SCREW	DY-103014010
57X	CAST CONTROL CAP ASSEMBLY	DY-U03164220	143	FRONT COVER SCREW-B	DY-C00141020
58	CLICKER	DY-101674011	155	BUSH	DY-104988010
59	CLICK PLATE	DY-101675011			
60	CLICK PLATE RETAINER	DY-101543012			