

LTXS1SHG3 / LTXS1SHLG3

NO.	PARTNAME	NO.	PARTNAME	NO.	PARTNAME
1	FRAME	44	DRIVE GEAR	96X	PALM SIDE PLATE ASSEMBLY
4	CLUTCH BAR ASSEMBLY	45	DRAG WASHER (L)	98	CONTROL DIAL
6	CLUTCH BAR SCREW	48	DRAG WASHER (D)	99	SPOOL COVER
7	LEVEL WIND ASSEMBLY	49	SLEEVE WASHER(OPTIONAL)	100	MAGNET HOLDER ASSEMBLY
8	PIPE	50	SLEEVE	105	SPOOL COVER SCREW (*3)
9	WORM SHAFT	51	GEAR SIDE PLATE	106	SPOOL SPACER (A)
10	BALL BEARING	51X	GEAR SIDE PLATE ASSEMBLY	107	BALL BEARING
12	IDLER (S)	53	ONE WAY CLUTCH	108	BEARING RETAINER
13	WORM SHAFT PIN	54	O-RING	112	DRAG SPACER
15	WORM SHAFT BUSHING (B)	55	BALL BEARING	121	SLIDE CAM SPRING (*3)
16	WORM SHAFT WASHER(OPTIONAL)	56	BEARING RETAINER	122	SLIDE CAM-H
17	E-RING	57	CAST CONTROL CAP	123	SLIDE CAM SCREW (*3)
18	PILLAR	61	TENSION WASHER	124	SLIDE CAM-D
19	LEVEL WIND PIN	62	SPOOL SPACER (B)	125	CLICK SPRING
20	SPACER(OPTIONAL)	63	LOCKING PIN	127	LINK PLATE
21	LEVEL WIND NUT	64	E-RING	128	LINK PLATE SCREW
22	FRONT COVER	65	LOCKING PIN SPRING		
23	FRONT COVER SCREW	66	GEAR SIDE COVER SCREW (A*5)		
24	BALL BEARING	71	DRAG SPRING WASHER (*2)		
25	CRANK SHAFT	73	STAR DRAG		
26	IDLER (L) WASHER (A)	77	LEAF SPRING		
27	IDLER (L)	78	HANDLE		
28	IDLER (L) WASHER (B)	78X	HANDLE COMPLETE		
29	BEARING PLATE	79	BUSHING (*2)		
30	E-RING	80	HANDLE KNOB (*2)		
31	BEARING PLATE SCREW (*2)	81	BALL BEARING (*2)		
33	CLUTCH CAM	82	HANDLE KNOB SCREW (*2)		
34	CLUTCH SPRING	83	HANDLE KNOB CAP (*2)		
35	KICK LEVER	85	HANDLE NUT		
36	KICK LEVER SPRING	86	HANDLE NUT RETAINER		
38	CLUTCH CAM SCREW	87	SCREW		
39	PINION YOKE	88	SPOOL		
40	PINION GEAR	88X	SPOOL COMPLETE		
41	PINION YOKE SPRING (*2)	89	BALL BEARING		
42	RATCHET	90	PIN		
43	RATCHET WASHER	96	PALM SIDE PLATE		

