



# ACRX1SH



# ACRX1SHL



Key#	Part Name	Key#	Part Name	Key#	Part Name
1	FRAME	55	BALL BEARING	167	CONTROL DIAL SCREW
4	CLUTCH BAR	56	BEARING RETAINER	178	MAGNET HOLDER COVER SCREW (*2)
6	CLUTCH BAR SCREW	57	CAST CONTROL CAP	190	DIAL DECO
7	LEVEL WIND ASSEMBLY	57X	CAST CONTROL CAP ASSEMBLY		
8	PIPE	58	CLICKER		
9	WORM SHAFT	59	CLICK PLATE		
10	BALL BEARING	60	CLICK PLATE RETAINER		
12	IDLER-S	61	TENSION WASHER		
13	WORM SHAFT PIN	62	SPOOL SPACER-B		
15	WORM SHAFT BUSHING-B	63	LOCKING PIN		
16	WORM SHAFT WASHER	65	LOCKING PIN SPRING		
17	E-RING	66	GEAR SIDE COVER SCREW-A(*5)		
18	PILLAR	71	DRAG SPRING WASHER(*2)		
19	LEVEL WIND PIN	73	STAR DRAG		
20	SPACER(OPTIONAL)	77	LEAF SPRING		
21	LEVEL WIND NUT	78	HANDLE		
22	FRONT COVER	78X	HANDLE COMPLETE		
23	FRONT COVER SCREW	79	BEARING(*2)		
24	BALL BEARING	80	HANDLE KNOB(*2)		
25	BRANK SHAFT	81	BEARING(*2)		
26	IDLER-L WASHER-A	82	HANDLE KNOB SCREW(*2)		
27	IDLER-L	83	HANDLE KNOB CAP(*2)		
28	IDLER-L WASHER-B	85	HANDLE NUT		
29	BEARING PLATE	86	HANDLE NUT CAP		
30	E-RING	87	SCREW		
31	BEARING PLATE SCREW(*2)	88	SPOOL		
33	CLUTCH CAM	88X	SPOOL COMPLETE		
34	CLUTCH SPRING	89	BALL BEARING		
35	KICK LEVER	90	PIN		
36	KICK LEVER SPRING	96	PALM SIDE PLATE		
39	PINION YOKE	96X	PALM SIDE PLATE ASSEMBLY		
40	PINION GEAR	98	CONTROL DIAL		
41	PINION YOKE SPRING(*2)	99	SPOOL COVER		
42	RATCHET	100	MAGNET HOLDER ASSEMBLY		
43	RATCHET WASHER	101	MAGNET HOLDER PLATE		
44	DRIVE GEAR	105	SPOOL COVER SCREW(*3)		
45	DRAG WASHER-L	106	SPOOL SPACER-A		
48	DRAG WASHER-D	107	BALL BEARING		
49	SLEEVE WASHER(OPTIONAL)	108	BEARING RETAINER		
50	SLEEVE	112	DRAG SPACER		
51	GEAR SIDE PLATE	118	CLUTCH SCREW		
51X	GEAR SIDE PLATE ASSEMBLY	124	SLIDE CAM-D		
53	ONE WAY CLUTCH	125	CLICK SPRING		
54	O-RING	148	WASHER(OPTIONAL)		