

## SSRX1H

Key #	Description	Order ID #	Key #	Description	Order ID #
1	FRAME	DY-106150020	58	CLICKER	DY-101674011
2	CLUTCH BAR PLATE-R	DY-104859010	59	CLICK PLATE	DY-101675011
3	CLUTCH BAR PLATE-L	DY-104860010	60	CLICK PLATE RETAINER	DY-101543012
4	CLUTCH BAR	DY-104674010	61	TENSION WASHER	DY-100073011
6	CLUTCH BAR SCREW	DY-104739010	62	SPOOL SPACER-B	DY-100074011
7	LEVEL WIND ASSEMBLY	DY-105527010	66	GEAR SIDE COVER SCREW-A	DY-104086010
8	PIPE	DY-101406010	67	GEAR SIDE COVER SCREW-B	DY-101507010
9	WORM SHAFT	DY-100017013	69	LUBE PORT CAP	DY-103305320
10	BALL BEARING	DY-102954010	70	LUBE PORT CAP SCREW	DY-101507030
12	IDLER-S	DY-100019010	71	DRAG SPRING WASHER	DY-100088010
13	WORM SHAFT PIN	DY-100020010	72	CLICK PLATE ASSEMBLY	DY-U00188030
15	WORM SHAFT BUSHING-B	DY-104642010	73	STAR DRAG	DY-105837060
16	WORM SHAFT WASHER	DY-100539030	77	HANDLE WASHER	DY-100933010
17	E-RING	DY-100047010	78	HANDLE	DY-U06192010
18	PILLAR	DY-102711010	78X	HANDLE COMPLETE	DY-106191010
19	LEVEL WIND PIN	DY-100464011	79	BALL BEARING	DY-102950010
20	SPACER(OPTIONAL)	DY-100025020	80	HANDLE KNOB	DY-105020010
21	LEVEL WIND NUT	DY-100288021	81	BALL BEARING	DY-102950010
22	FRONT COVER	DY-106151010	82	HANDLE KNOB SCREW	DY-100180010
23	FRONT COVER SCREW	DY-100152010	83	HANDLE KNOB CAP	DY-105023010
24	BALL BEARING	DY-102952010	85	HANDLE NUT	DY-104094150
25	CRANK SHAFT	DY-105257010	86	HANDLE NUT RETAINER	DY-103642170
27	IDLER-L	DY-101938020	87	SCREW	DY-101202020
28	IDLER-L WASHER-B	DY-100646020	88	SPOOL	DY-U06665010
29	BEARING PLATE	DY-104411010	88X	SPOOL COMPLETE	DY-106664010
30	E-RING	DY-100047010	89	BALL BEARING	DY-104540010
31	BEARING PLATE SCREW	DY-100028070	90	PIN	DY-104399010
33	CLUTCH CAM	DY-102893010	96	PALM SIDE PLATE	DY-106159020
34	CLUTCH SPRING	DY-102688010	96X	PALM SIDE PLATE ASSEMBLY	DY-U06159020
35	KICK LEVER	DY-106155010	98	CONTROL DIAL	DY-106236010
36	KICK LEVER SPRING	DY-104137010	99	SPOOL COVER	DY-106232010
37	CAM PLATE	DY-104354010	100	MAGNET HOLDER ASSEMBLY	DY-U06233010
38	CAM PLATE SCREW	DY-101177050	105	SPOOL COVER SCREW	DY-103423010
39	PINION YOKE	DY-102073010	106	SPOOL SPACER-A	DY-101850010
40	PINION GEAR	DY-105846010	107	BALL BEARING	DY-104541010
41	PINION YOKE SPRING	DY-102465010	108	BEARING RETAINER	DY-102976010
42	RATCHET	DY-106087010	118	CLUTCH SCREW	DY-103013020
43	RATCHET WASHER	DY-106177010	124	SLIDE CAM-D	DY-106235010
44	DRIVE GEAR	DY-102870030	125	CLICK SPRING	DY-105429010
45	DRAG WASHER-L	DY-102377011	127	LINK PLATE	DY-102894010
46	DRAG WASHER-D1	DY-100057020	128	LINK PLATE SCREW	DY-103014010
47	DRAG WASHER-A	DY-100985010	133	HOOK HOLDER	DY-102898020
48	DRAG WASHER-D2	DY-100986010	134	HOOK HOLDER WASHER	DY-101168020
49	SLEEVE WASHER(OPTIONAL)	DY-100086060	135	HOOK HOLDER SCREW	DY-100246030
50	SLEEVE	DY-104537010	136	HOOK HOLDER SPRING	DY-102968011
51	GEAR SIDE PLATE	DY-106157060	144	LOCK LEVER	DY-106161020
51X	GEAR SIDE PLATE ASSEMBLY	DY-U06157060	145	CLICK PIN SPRING	DY-103643011
53	ONE WAY CLUTCH	DY-104088010	146	CLICK PIN	DY-102494010
54	O-RING	DY-100209020	155	BUSH	DY-104365010
55	BALL BEARING	DY-102381010	167	CONTROL DIAL SCREW	DY-104901010
56	BEARING RETAINER	DY-104461010	168	CONTROL DIAL WASHER	DY-105055010
57	CAST CONTROL CAP	DY-105871030	178	MAGNET HOLDER COVER SCREW	DY-104900010
57X	CAST CONTROL CAP ASSEMBLY	DY-U05871030			