





KTB1SHG2



KTB1SHLG2



Key#	Part Name	Key#	Part Name	Key#	Part Name
1	FRAME	56	BEARING RETAINER	123	SLIDE CAM SCREW
4	CLUTCH BAR ASSEMBLY	57	CAST CONTROL CAP	124	SLIDE CAM-D
6	CLUTCH BAR SCREW	61	TENSION WASHER	125	CLICK SPRING
7	LEVEL WIND ASSEMBLY	62	SPOOL SPACER-B	127	LINK PLATE
8	PIPE	63	LOCKING PIN	128	LINK PLATE SCREW
9	WORM SHAFT	65	LOCKING PIN SPRING	138	BUSHING-C
10	BEARING	66	GEAR SIDE COVER SCREW-A (*3)	166	WASHER
12	IDLER-S	67	GEAR SIDE COVER SCREW-B (*2)		
13	WORM SHAFT PIN	71	DRAG SPRING WASHER (*2)		
15	WORM SHAFT BUSHING-B	73	STAR DRAG ASSEMBLY		
16	WORM SHAFT WASHER	77	LEAF SPRING		
17	E-RING	78	HANDLE		
18	PILLAR	78X	HANDLE COMPLETE		
19	LEVEL WIND PIN	79	BEARING (*2)		
20	SPACER(OPTIONAL)	80	HANDLE KNOB (*2)		
21	LEVEL WIND NUT	81	BALL BEARING (*2)		
22	FRONT COVER	82	HANDLE KNOB SCREW (*2)		
23	FRONT COVER SCREW	83	HANDLE KNOB CAP (*2)		
24	BALL BEARING	85	HANDLE NUT		
25	CRANK SHAFT	86	HANDLE NUT RETAINER		
27	IDLER-L	87	SCREW		
28	IDLER-L WASHER-B	88	SPOOL ASSEMBLY		
29	BEARING PLATE	88X	SPOOL COMPLETE		
30	E-RING	89	BALL BEARING		
31	BEARING PLATE SCREW (*2)	90	PIN		
33	CLUTCH CAM	91	BRAKE HOLDER		
34	CLUTCH SPRING	92	BRAKE SHOE (*4)		
35	KICK LEVER	93	BRAKE SHOE SPRING (*4)		
36	KICK LEVER SPRING	94	MAGNET PLATE		
39	PINION YOKE	95	SCREW (*2)		
40	PINION GEAR	96	PALM SIDE COVER		
41	PINION YOKE SPRING (*2)	96X	PALM SIDE COMPLETE		
42	RATCHET	98	CONTROL DIAL		
43	RATCHET WASHER	99	SPOOL COVER		
44	DRIVE GEAR	100	MAGNET HOLDER ASSEMBLY		
45	DRAG WASHER-L	105	SPOOL COVER SCREW		
46	DRAG WASHER-D	106	SPOOL SPACER-A		
49	SLEEVE WASHER(OPTIONAL)	107	BALL BEARING		
50	SLEEVE	108	BEARING RETAINER		
51	GEAR SIDE COVER	112	DRAG SPACER		
51X	GEAR SIDE COMPLETE	114	WASHER(OPTIONAL)		
53	ONE WAY CLUTCH	118	CLUTCH SCREW		
54	O-RING	121	SLIDE CAM SPRING		
55	BALL BEARING	122	SLIDE CAM-H		