

TLX15H-150

Key #	Description	Order ID #		Key #	Description	Order ID #
1	FRAME	DY-105920050		69	LUBE PORT CAP	DY-103305460
2	CLUTCH BAR PLATE-R	DY-104636010		70	LUBE PORT CAP SCREW	DY-101507040
3	CLUTCH BAR PLATE-L	DY-104637010		71	DRAG SPRING WASHER	DY-100088010
4	CLUTCH BAR	DY-105531020		72	CLICK PLATE ASSEMBLY	DY-U11105030
6	CLUTCH BAR SCREW	DY-104739020		73	STAR DRAG	DY-U05564130
7	LEVEL WIND ASSEMBLY	DY-105921020		77	HANDLE WASHER	DY-105565020
8	PIPE	DY-103286010		78	HANDLE	DY-U07017010
9	WORM SHAFT	DY-103287010		78X	HANDLE COMPLETE	DY-107015010
10	BUSHING	DY-102605010		79	BUSHING	DY-100196010
12	IDLER-S	DY-100019010		80	HANDLE KNOB	DY-107020010
13	WORM SHAFT PIN	DY-100020010		81	BUSHING	DY-100196010
15	WORM SHAFT BUSHING-B	DY-104642010		82	HANDLE KNOB SCREW	DY-100180020
16	WORM SHAFT WASHER	DY-100539020		83	HANDLE KNOB CAP	DY-103957010
17	E-RING	DY-100047010		85	HANDLE NUT	DY-104094150
18	PILLAR	DY-102711010		86	HANDLE NUT RETAINER	DY-103642020
19	LEVEL WIND PIN	DY-100464011		87	SCREW	DY-101202030
20	SPACER(OPTIONAL)	DY-100025020		88	SPOOL	DY-U07019010
21	LEVEL WIND NUT	DY-100288021		88X	SPOOL COMPLETE	DY-107018010
22	FRONT COVER	DY-105923071		89	BALL BEARING	DY-107000010
23	FRONT COVER SCREW	DY-106381030		90	PIN	DY-104399010
24	BALL BEARING	DY-107002010		96	PALM SIDE COVER	DY-106048050
25	CRANK SHAFT	DY-105257010		96X	PALM SIDE PLATE ASSEMBLY	DY-U06048050
27	IDLER-L	DY-101938020		98	CONTROL DIAL	DY-106049030
28	IDLER-L WASHER-B	DY-100646010		99	SPOOL COVER	DY-105941010
29	BEARING PLATE	DY-104411020		100	MAGNET HOLDER ASSEMBLY	DY-U15943010
30	E-RING	DY-100047010		105	SPOOL COVER SCREW	DY-103423010
31	BEARING PLATE SCREW	DY-100028070		106	SPOOL SPACER-A	DY-101850010
33	CLUTCH CAM	DY-105750010		107	BALL BEARING	DY-107001010
34	CLUTCH SPRING	DY-102688010		108	BEARING RETAINER	DY-102976010
35	KICK LEVER	DY-102307011		117	CLUTCH WASHER	DY-100539030
36	KICK LEVER SPRING	DY-104137010		118	CLUTCH SCREW	DY-103013020
37	CAM PLATE	DY-104639011		124	SLIDE CAM-D	DY-105940020
38	CAM PLATE SCREW	DY-100035050		125	CLICK SPRING	DY-105958010
39	PINION YOKE	DY-102073010		133	HOOK HOLDER	DY-102898020
40	PINION GEAR	DY-105847010		134	HOOK HOLDER WASHER	DY-101168020
41	PINION YOKE SPRING	DY-102465010		135	HOOK HOLDER SCREW	DY-100246030
42	RATCHET	DY-100818020		136	HOOK HOLDER SPRING	DY-102968011
43	RATCHET WASHER	DY-103772010		141	HOOD	DY-106045040
44	DRIVE GEAR	DY-102871030		142	HOOD SCREW	DY-103828030
45	DRAG WASHER-L	DY-102377011		143	FRONT COVER SCREW-B	DY-106381030
46	DRAG WASHER-D1	DY-100057020		144	LOCK LEVER	DY-105942010
47	DRAG WASHER-A	DY-100985010		145	CLICK PIN SPRING	DY-103643010
48	DRAG WASHER-D2	DY-104122010		146	CLICK PIN	DY-102494010
49	SLEEVE WASHER(OPTIONAL)	DY-100086010		147	GUIDE PIN	DY-103288020
50	SLEEVE	DY-104537020		155	BUSH	DY-104365010
51	GEAR SIDE PLATE	DY-106046150		166	WASHER (G/METAL E-RING-BALL BEARING)	DY-100647050
51X	GEAR SIDE PLATE ASSEMBLY	DY-U06046150		167	CONTROL DIAL SCREW	DY-104900010
53	ONE WAY CLUTCH	DY-105718010		168	CONTROL DIAL WASHER	DY-105985040
54	O-RING	DY-100209020		170	FRAME PLATE	DY-105529010
55	BALL BEARING	DY-102381010		171	CLUTCH BAR TRIM	DY-105532100
56	BEARING RETAINER	DY-104461010		172	CLUTCH BAR TRIM SCREW (*2)	DY-100526010
57	CAST CONTROL CAP	DY-105572050		174	DRAG NUT	DY-105562011
57X	CAST CONTROL CAP ASSEMBLY	DY-U05572050		175	DRAG NUT WASHER	DY-105567010
58	CLICKER	DY-101674011		176	DRAG NUT SPRING	DY-105590010
59	CLICK PLATE	DY-101675011		177	MAGNET HOLDER COVER	DY-105944020
60	CLICK PLATE RETAINER	DY-101543012		178	MAGNET HOLDER COVER SCREW (*2)	DY-104900010
61	TENSION WASHER	DY-100073011		181	FRAME DECO A	DY-105925030
62	SPOOL SPACER-B	DY-100074021		182	FRAME DECO B	DY-105926030
66	GEAR SIDE COVER SCREW-A	DY-100202060		190	DIAL DECO	DY-105946072
67	GEAR SIDE COVER SCREW-B	DY-100202050				